

- 5. For gate installation use anchors M16x240 or longer. Anchors must be over concete surface 80mm minimum.
- 6. Use this drawing as suggestion. Exact foundation dimensions have to be verified concerning local soil parameteres and freeze depth.

Designed by I. Kłeczek	File name OFP 8000 R		Date 2017-07-05	Q-ty	Scale 1:28
\wedge	1	ODEN foundation plan 8000 right			Material
HALSANG		Number OFP	8000R	Format A4	Drawing